

Partie à jeter
Please discard
this part

• Adaptation de vanne filetée **FR**

① Mesurer le diamètre du filetage: M28 ou M30

② Mesurer le pas de vis : 1,0 mm ou 1,5 mm

③ Correspondance et installation

✓ M30 x 1,5 mm : Connexion directe à la TRV
 ✓ M28 x 1,5 mm : Utiliser l'adaptateur M28
 ✗ M30 x 1,0 mm
 ✗ M28 x 1,0 mm

Essayez les tiges d'éjection de la plus courte à la plus longue jusqu'à ce qu'une s'adapte à la vanne thermostatique du radiateur (TRV).

Pas: 1,5 mm

M28

Adaptateur RAVL

Adaptateur RAV

H13 mm

Pas: 1 mm

Adaptateur RA

Adaptateur GIA

H8,6 mm

Adaptateur CAL

M30

Pas: 1 mm

• Non-Threaded Valve Adaption **EN**

① Identify the valve type

Use the grooves below to match the shape of your valve.

② Select Adapter

Select adapter according to the adapter diagram.

③ Install Adapter and TRV

Try ejector rods from shortest to longest until one fits the TRV.

H15,3 mm

H17,3 mm

H18,8 mm

H24,3 mm

M28

RAVL Adapter

RAV Adapter

H13 mm

RA Adapter

GIA Adapter

H8,6 mm

CAL Adapter

M30

PITCH 1.5mm

PITCH 1.0mm

• Threaded Valve Adaption **EN**

① Measure the thread diameter: M28 or M30

② Measure the thread pitch: 1.0 mm or 1.5 mm

✓ M30 x 1.5mm: Connect to TRV
 ✓ M28 x 1.5 mm: Use M28 adapter
 ✗ M30 x 1.0 mm
 ✗ M28 x 1.0 mm

Pitch: 1 mm

Pitch: 1.5 mm

Pitch: 1 mm

Pitch: 1.5 mm

Access Multilingual Instructions

avidsen

Access Multilingual Instructions

Ligne de pliage/Folding line